

(P/N: SP062)

MAGNASPHERE HSS INSTALLATION INSTRUCTIONS: All Models of (L2S & L2D) 000-Series

CAUTION: MAGNASPHERE MAGNET MODULES AND ANTI-REMOVAL MAGNETS ARE EXTREMELY POWERFUL: TAKE PRECAUTIONS TO AVOID THE MAGNETIC ATTRACTION OF SHARP TOOLS AND TO AVOID INJURY FROM THE PINCHING FORCE BETWEEN THE MAGNET AND FERROUS METALS OR OTHER MAGNETS.

Attention: modules à aimants Magnasphere et anti-enlèvement aimants sont très puissants: prendre des précautions pour éviter l'attraction magnétique d'outils tranchants et à éviter les blessures de la force de pincement entre l'aimant et les métaux ferreux ou d'autres aimants


Required Tools and Components


TAMPER CIRCUT

Provided by Installer


- Provided by Manufacturer (per module set) 1 HSS switch module
- 1 HSS magnet module
- 7 switch & magnet module self-tapping screws (#10-32 x 2")
- 2 self-tapping screws (#6, 1" long)
- 1 HSS switch module template
- 1 HSS magnet module template
- 1 anti-rotational threaded stud (set screw)
- 2 1/16" plastic spacer plates
- 1 Removal-Tamper magnet
- 2 Removal-Tamper caps


Power drill Drills bits: #35,#21, 3/16" Phillips screwdriver or a Phillips bit for use in the drill/bit-driver Rule (or any linear measuring instrument) A center punch (& hammer) for more accurate hole locations may be used A pilot drill bit for screws (3/32" or smaller) may be used Additional 1/16" SPACERS (10/ BAG - MAGNASPHERE P/N SP062)





Plan to mount the switch module to the door frame, close to the door/frame gap and without door-swing interference. The magnet module must be mounted directly below the switch. Spacers may be used to attain sufficient alignment. Recommended placement for the set is 8 inches from the latch side of the door**, at the top. Provided templates may assist locating holes. *A gap up to 1/8" is required for compliance with UL634 Level 2, C634 high security standard. For non High Security installations: up to 3/16" gap.






Plan to mount the switch module to the door stop, close to the door but without door-closure interference. The magnet module must be mounted directly below the switch. Spacers may be used to attain sufficient alignment. Recommended placement for the set is 8 inches from the latch side of the door**, at the top. Provided templates may assist locating holes. *A gap up to 1/8" is required for compliance with UL634 Level 2, C634 high security standard. For non High Security installations: up to 3/16" gap.

(continued) ingress door instructions:

(continued) egress door instructions:

A clearance hole for the anti-rotational screw must be drilled into the door frame before mounting the switch module; its position is given on the templates. For anti-tamper purposes, the switch module has two sites for an anti-rotational threaded stud; only one site will be used depending on which installation plan is chosen. Thread the screw into hole until about 1/4" of the screw remains outside the module.



**Recommended placement to meet door opening and alarm requirements of UL634 Level 2. This guide is one means to meet this standard. Installations which fulfill its requirements are not restricted to the specific recommendations in this instruction set.

Additional mounting hardware, resistor configurations, cable lengths, and other variants are available.

#5977873, #6506987, #6803845, #7291794, #7944334, #8314698, #6087936, #6603378, #7023308, #RE39731, #8228191, #8648720 & Other Patents Pending 2-2017 L2X-0XX-INST REV3

www.magnasphere.com

SNASPHERE"

MAGNASPHERE N22 W22931 Nancys Ct. Ste 3, Waukesha, WI 53186 tel 262.347.0711 fax 262.347.0710